

1 Lubrication chart

Edition: 2019-12, replaces edition 2018-06

Marine gearboxes without built-in disc clutch

Lubricant type

Marine diesel engine oil Gear oil Requirements

- SAE 30 (ISO VG 100)
 - FZG ≥ 11

٠

Castrol		E‰onMobil	
 Alphasyn HG 100^a ^b Castrol CDX 30^a Castrol MHP 153 Castrol Alpha SP 100^a Hyspin AWH-M 100^a Castrol TLX PLUS 203 Castrol TLX PLUS 303 Castrol HLX 30 	 Delo 1000 Marine 30^a Taro 20 DP 30 / 30X Taro 30 DP 30 / 30X Meropa 100 Meropa MG 100^a Meropa XL 100^a Meropa Synthetic EP 100^b Clarity Synthetic EA Gear Oil 100^c 	 Mobil Delvac 1330 Mobil Delvac 1630 Mobil SHC 627^{a b} Mobil DTE 10 Excel 100 Mobilgear 600 XP 100^a Mobilgear XMP 100^a Mobilgard 312 Mobilgard ADL 30 	 Shell Melina S 30 Shell Melina 30 Shell Gadinia AL 30^a Shell Gadinia S3 30 Shell Argina S2 30 Shell Argina S3 30 Shell Sirius 30 Shell Rimula X 30 Shell Rimula R 3+30 Shell Omala S 2 GX 100 (Shell Omala 100) Shell Omala F 100^a
 Titan Universal HD 30 Titan Universal XT 30 Renolin CLP 100^a Plantogear 100 S^c 	 Carter EP 100 Caprano TD 30 Rubia S 30 Caprano MT 30 	 Multi Fluid SAE 30 Eco Gear 100 M^a 	Marine • GulfSea Gear 100 • GulfSea Power MDO 3015/3020
• GEM 4-100 N ^b	 Disola M 3015 Disola MT 30 Epona Z 100 Valvoline. Valmarin TP-1230 		

b. Synthetic oil (PAO only)

c. Biologically degradable oils (EAL)



Observe when selecting oil for use in REINTJES gearboxes:

- If the oil temperature is lower than
 - + 10 °C / 50 °F (SAE 30)
 - + 15 °C / 59 °F (SAE 40)
 - a sump heating installation is required (special equipment must be fitted to the gearbox).
- Lubricants approved by REINTJES meet all operational requirements and need no further additives.
 Further additives may even be harmful.
- Highly alkaline engine oils (BN > 20) must not be used with built-in disc clutch.
- Observe the manufacturer's safety data sheet for safely handling the lubricant.

Observe when changing oil:

- Observe the oil change intervals and oil analysis intervals specified in the operating manual.
- Replace filter elements when changing oil. Clean the venting filter thoroughly. Carry out a first check for contamination approx. 12 hours after commissioning.
- The oil level must be between the dipstick markings. The operating oil volume indicated on the type plate or the drawing of installation is a reference value.
- For flushing and cleaning of the gearbox use the operating oil. Remove cleaning oil from gearbox, oil filter and heat exchanger as thoroughly as possible.
- The gearbox is filled with VCI preservation oil when delivered. When the gearbox is put into operation, drain the VCI preservation oil and fill in operating oil. Any small amount of VCI preservation oil remaining may be mixed with the operating oil.

NOTICE

- The oil types listed in the lubrication chart are defined by the responsibility of the oil companies. The oils are suitable for the use in gearboxes and are in accordance with the REINTJES specification. The oil companies are responsible to keep the compositions of the oils identical as specified for this oil chart.
- ▶ REINTJES is neither liable for correctness of these data nor for any amendments occurring.
- ▶ If other oils shall be used please contact REINTJES first.
- ▶ REINTJES does not accept responsibility for any damages due to use of unsuitable oil.

NOTICE

Danger of hydrolysis

EAL lubricants are as a rule based on synthetically produced esters. There is always a danger of the used EAL lubricants to hydrolyse.

- Minimise the water content of the EAL lubricant for example by using adsorbers (special equipment).
- Observe the special information for EAL lubricants on oil change, flushing, and shutdown periods in the REINTJES operation description BV2379 "Guidelines for changing oil".
- Contact REINTJES service when using EAL lubricants for the first time.