

# 1 Lubrication chart

Edition: 2024-01, replaces edition 2022-10

## Marine gearboxes without built-in disc clutch

The oils must fulfill the advanced requirements on thermal stability. These gearboxes require a high scuffing load capacity.

Lubricant type
Marine diesel engine oil
Gear oil

- Requirements
  - SAE 40 (ISO VG 150)
  - FZG ≥ 12

•

 Operating temperature up to 120 °C (248 °F), temporary 130 °C (266 °F)

<ul> <li>Titan Universal HD 40</li> <li>Titan Universal XT 40</li> <li>Plantogear 150 S<sup>c</sup></li> <li>Carter EP 150</li> <li>Disola M 4015</li> <li>Disola MT 40</li> <li>Super Tauro 150</li> <li>Klübersynth GEM 1-150 N<sup>a</sup></li> <li>Klübersynth Klübersynth</li> </ul>	• • • •	Shell Gadinia AL 40 <sup>a</sup> Shell Gadinia S3 40 Shell Omala S2 GX 150 (Shell Omala 150) Shell Omala F 150 <sup>a</sup> Shell Omala S4 GXV 150 <sup>c</sup> (Shell Omala HD 150 <sup>a b</sup> ) Shell Rimula X 40 Shell Rimula R3+ 40 Shell Sirius 40	<ul> <li>Castrol MHP 154</li> <li>Hyspin AWH-M 150<sup>a</sup></li> <li>Castrol Alpha SP 150</li> <li>Castrol HLX 40<sup>d</sup></li> <li>Alphasyn HG 150<sup>a b</sup></li> <li>Alphasyn T 150<sup>b</sup></li> </ul>	•	Exaco Chevron Control	Mobil Delvac 1340 Mobil Delvac 1640 Mobilgear 600 XP 150 Mobilgear SHC XMP 150 <sup>a b</sup> Mobilgear XMP 150 <sup>a</sup> Mobilgear XMP 150 <sup>a</sup> Mobilgard ADL 40 Mobilgard 1 SHC <sup>b</sup>
Plantogear 150 S <sup>o</sup> Disola M1 40     Muber synth	•	Titan Universal XT 40	<ul><li>Carter EP 150</li><li>Disola M 4015</li></ul>	-	Marino 3 SAE 40	GEM 1-150 N <sup>a</sup>
Epona Z 150     GEM 4-150 N <sup>a b</sup> Klüberbio EG2-150 <sup>a c</sup>	•	Plantogear 150 S <sup>o</sup>	• Epona Z 150			GEM 4-150 N <sup>a b</sup>
Guif       Marine         • GulfSea Gear 150       • Eco Gear 150 S <sup>a b</sup>	•		Eco Gear 150 S <sup>a b</sup>			

- a. Oil with greystaining test result "high"
- b. Synthetic oil (PAO only)
- c. Biologically degradable oils (EAL)
- d. NATO approval O-278



### Observe when selecting oil for use in REINTJES gearboxes:

- If the oil temperature is lower than
  - + 10 °C / 50 °F (SAE 30)
  - + 15 °C / 59 °F (SAE 40)

a sump heating installation is required (special equipment must be fitted to the gearbox).

- Lubricants approved by REINTJES meet all operational requirements and need no further additives. Further additives may even be harmful.
- Observe the manufacturer's safety data sheet for safely handling the lubricant.

#### Observe when changing oil:

- Observe the oil change intervals and oil analysis intervals specified in the operating manual.
- Replace filter elements when changing oil. Clean the venting filter thoroughly. Carry out a first check for contamination approx. 12 hours after commissioning.
- The oil level must be between the dipstick markings. The operating oil volume indicated on the type plate or the drawing of installation is a reference value.
- For flushing and cleaning of the gearbox use the operating oil. Remove cleaning oil from gearbox, oil filter and heat exchanger as thoroughly as possible.
- The gearbox is filled with VCI preservation oil when delivered. When the gearbox is put into operation, drain the VCI preservation oil and fill in operating oil. Any small amount of VCI preservation oil remaining may be mixed with the operating oil.

## NOTICE

- The oil types listed in the lubrication chart are defined by the responsibility of the oil companies. The oils are suitable for the use in gearboxes and are in accordance with the REINTJES specification. The oil companies are responsible to keep the compositions of the oils identical as specified for this oil chart.
- REINTJES is neither liable for correctness of these data nor for any amendments occurring.
- ▶ If other oils shall be used please contact REINTJES first.
- REINTJES does not accept responsibility for any damages due to use of unsuitable oil.

### NOTICE

#### **Danger of hydrolysis**

EAL lubricants are as a rule based on synthetically produced esters. There is always a danger of the used EAL lubricants to hydrolyse.

- Minimise the water content of the EAL lubricant for example by using adsorbers (special equipment).
- Observe the special information for EAL lubricants on oil change, flushing, and shutdown periods in the REINTJES operation description BV2379 "Guidelines for changing oil".
- Contact REINTJES service when using EAL lubricants for the first time.